

Thank you for choosing a Polyworld Pool! We know you will have years of fun.

This is a guide to the installation of your new pool. You are welcome to call our office and discuss the process, and you can find more information and videos on our website. Our delivery driver can assist for a short while to help you install.

CONTENTS

- 1) Site Preparation
- 2) Offload and Place
- 3) Framing assembly
- 4) Skimmer Box
- 5) Return fish eye
- 6) Fencing
- 7) Electrical
- 8) Water

1) Site Preparation

The Schooner Pool has a footprint of 5,000 mm x 2,500 mm

The pool needs to stand on a very level surface (if the base is not level, the water line will appear odd)

The base needs to be concrete or compacted fill

Concrete needs to be a grade 15, a minimum of 100mm thick, with one layer of mesh, when on stable soil – thicker and using a stronger grade on poor soil type.

Minimum 5,100 mm long 1,600 mm wide

Compacted fill can be 150mm of crusher dust, but it needs at least 300mm extra surround to stop the edge collapse – or the base can be contained within treated sleepers and star pickets. Any loss of fill must be attended to immediately, to re-support the base.

Do not have any sharp rocks or steel in the base, you risk penetrating the base of the pool.

The pool must not be placed against a wall – it must be free (150 mm) to expand with the water pressures.

2) Offload and Place

- The delivery truck will bring the pool, with a stripped down frame, and the filter with accessories as ordered.
- If you have a crane available, that's great, but otherwise, the pool can be dropped on the floor and with 4 men it can be manhandled into position.
- The pool can even be turned on it's side and moved around.
- The pool can be lifted with a pair of 2 wheel trolleys
- Do NOT use a forklift - unless you have tines longer than 2,500mm, for risk of puncturing the base.
- Position 3 ground straps so that they go under the pool.
- Don't permit the crusher dust to be disturbed too much, keep it as flat as possible.

3.1) FRAMING ASSEMBLY – Pool first, frame last method

Identify the following, and lay them in position.

3 under pool straps,

2 'horse shoe' semicircle straps

2 side frames

8 x M10 Stainless bolts, nuts, washers, for the side/ring connection. Get yourself an Alan key and/or spanner of correct size.

6 x M8 Stainless bolts, nuts, washers, for the 'foot' connection. Get yourself an Alan key or spanner of correct size

Ensure that the 'horse shoe rings' are facing the right way up – the taper on the flange must point inwards.

Ensure that the frames are the correct way around – the taper on the flange points inwards.

Ensure that the tie-straps are under the pool, spaced along the pool to suit the spacing of the side frames

Chose the end that you want your skimmer, pump, return, and outlet on, and position the pool accordingly.

1) Lean up the 2 side frames against the side of the pool. This task is easiest if you use a vehicle tie-down strap from one side to the other, to prevent frames from falling – otherwise you need an additional assistant at each side to hold the side frame up.

2) Place the feet of the side frame over the tie straps stubs, and make the bolt connection – secure but not tight.

3) Now bring up one semicircle end and make the flange connection to the side frame flange, secure but not tight. Snug the pool against this end, in anticipation of the 'other end' needing to be attached.

4) Next - do the 'other end' semicircle to frame connection. If you find the semicircle is leaving a gap and you can't get the bolt in, then use the 4 – M10 studs, each 200mm long, as a temporary method of drawing the second end in tight – then replace the studs (one at a time) with the stainless bolts.

5) Check that the pool is centralised, the straps are in correct positions, and that the end semicircles are level and tighten all connections.

3.2) ALTERNATE METHOD OF ASSEMBLING FRAMING - Frame first, pool last method

In this method, the 3 straps, the 2 sides, and ONE end is pre-assembled.

Then the pool is walked in from one end

Then the last semicircle end is fitted.

This method requires at least 4 strong men to be able to lift and carry/slide the pool into the open ended frame. This method is not recommended on a crusher dust base, as the crusher gets disturbed during the manhandling.

You should not attempt to lift a pool over a completed frame without a crane.

4) Fitting the skimmer

Whilst it is quite possible for a tradesman or handyman to DIY the installation of a skimmer box, we do prefer to do it in the controlled conditions of our factory.

- 1) Decide on which the end to position the skimmer.
- 2) Decide on the water level – usually 150mm down from the inside edge of the pool lip – this will be the horizontal centre line of the skimmer cut-out.
- 3) Position the skimmer flange inside the pool, (Careful, there is a top and a bottom to this) - align vertically and horizontally with the 150mm water line on the centre of the skimmer, and, using the flange as a template, mark out the INSIDE of the flange. This will be the cut-out. Don't over size the cut-out.
- 4) Use a drill and jigsaw, cut-out the skimmer hole
- 5) Mark and drill the screw holes – (careful, there is a top and bottom to this), and de-bur the surfaces well
- 6) Fix the skimmer box, using the screws and the gaskets provided. Ensure you have a good seal. Silicone can be used if required. The plastic can be sanded flat if it does not seal.

5) Fitting the return fish-eye

- 1) To fit the fish-eye, it is best to partially fill the pool with 'settling water', so the weight of the water makes the pool sit firmly and so the ends are pulled well down. Select a position that is not too low so that it does not interfere with the end semi-circle ring, and not so high that it is above the water line. Usually 270mm down from the inside lip to the centre line of the hole.
 - 2) Using a hole saw of the correct size, drill the fish-eye hole, and fit the fish-eye with gaskets, use silicone sealer if required.
- NOTE:- the extra thick translucent polyurethane rubber washer (OD55 ID30 T6) – goes between the fish-eye and the hose coupling.

6) Pump & Filter

An easy task, requiring an inlet hose from the skimmer to the suction side of the pump, and a return hose from the filter to the fish-ball.

Read the instructions with the filter kit for full details.

7) Fencing

Check with your local council – they will all need childproof fence. This should be completed before you introduce any 'settling' water or before rainwater makes this a drowning hazard. Always leave the gate valve open to reduce the chance of rainwater catchment.

Your pool kit will include a 'Resuscitation Sign' – which you will need to display.

8) Electrical

The pump is fitted with a 2m cable and 3 prong 10A plug. Have your electrical install a weatherproof socket. Be aware of water splash from the pool. Ensure the circuit has a 'Safety Switch RCD'.

You might choose to use a timer to control the pumping times.

9) Water

Fill with water, but only turn filter pump on once there is enough water to flood the skimmer – never run the pump dry.

Use the floating chlorine dispenser with one tablet, and close the dispenser shutters to give minimum chlorine use.

A test kit and a cleaning kit are provided

Use your pool shop to do a professional water test occasionally, to keep the water sparkling.

Enjoy!